

Chain Condom™ Road Bike Install Instructions

Chain Condom™ is easy to use and takes less than a minute to put on. It was designed primarily for use with road bikes, but Chain Condom™ works with mountain bikes too. Just follow the 3 simple steps below to put Chain Condom™ on your road bike.

Step 1:



Shift your bike into the position that makes it easiest to put on the Chain Condom™.

Just shift the front derailleur so that the chain is on the BIG ring up front, and shift the rear derailleur into the SMALLEST cog in the rear.

Make sure to leave the crank arm positioned next to the front derailleur. (Your pedals DON'T go inside the Chain Condom™.)

Step 2:



Open the Chain Condom™ by separating the VELCRO®, and, starting from underneath the chain rings, slide the open cover over both front chain rings.

Step 3:

Continue covering the chain and rear derailleur by pulling the Chain Condom™ cover back toward and then up and over the rear derailleur. Once you've got the Chain Condom™ pulled over the rear derailleur, simply press the VELCRO® together.



Questions? Email us at sales@chaincondom.com or call +1-512-705-5389.